

Searching High-Energy Neutrinos with IceCube and Python




Robert Franke, Eike Middell, Sebastian Panknin, Bernhard Voigt for the IceCube Collaboration



Outline

- Introduction: IceCube Neutrino Astronomy
- Data flow (IceTray software framework)
- Controlling IceTray with Python
- Prototyping with Python
- Analysis Tools

Neutrino-Astronomy



The IceCube Telescope



Detection Pricinple HV Divider Penetrator LED Flasher Board DOM Mainboard Mu-metal grid Delay Board atm v PMT RTV gel Glass Pressure Housing

IceCube Collaboration

USA:

Bartol Research Institute, Delaware Pennsylvania State University UC Berkeley UC Irvine Clark-Atlanta University University of Maryland University of Wisconsin-Madison University of Wisconsin-River Falls Lawrence Berkeley National Lab. University of Kansas Southern University and A&M College, Baton Rouge University of Alaska, Anchorage

Sweden:

Uppsala Universitet
Stockholm Universitet

UK:

Oxford University

Germany:

Universität Mainz DESY-Zeuthen Universität Dortmund Universität Wuppertal Humboldt Universität MPI Heidelberg RWTH Aachen

Netherlands:

Utrecht University

Belgium:

Université Libre de Bruxelles Vrije Universiteit Brussel Universiteit Gent Université de Mons-Hainaut

Japan:

Chiba university


30 institutions, ~250 members http://icecube.wisc.edu

New Zealand: University of

Canterbury




Data Flow





IceTray



- IceTray serves data stream
 - Frame / Pop / Stop / Push
- Modules for different tasks
 - access to frame content
- Several people write modules
 - clear interface (construct, configure, physics)

I3Module
context
frame
Configure
Physics(Frame)

Implemented in C++, lots of STL and boost stuff



Where do we use Python?

- Chain C++ module together (steering file)
 - no need to write C++ for non-module developers
 - extremely flexible, lots of OS functions, rapid development, easy to learn
 - need to interface IceTray to Python
- Analyzer's daily work histograms, plots, calculations, selections
 - need to extract data from binary files or expose IO
- Toy simulations for fast prototyping
 - test bed for new ideas, easy to debug
 - interactive: plot wherever you want to see your data
 - need to write Modules in Python





IceTray – Steering Files

```
#!/usr/bin/env python
import I3Tray
import os
import sys
import os.path
I3Tray.load("libdataclasses")
I3Tray.load("libdataio")
I3Tray.load("libsim-services")
I3Tray.load("libsimple-generator")
def main():
    nevents = sys.argv[1]
    run = sys.arqv[2]
    tray = I3Tray. I3Tray()
    tray.AddService("I3SPRNGRandomServiceFactory", "random")(
        ("Seed", run))
    tray.AddModule("I3Muxer", "muxer")
    tray. AddModule("I3SimpleGenerator", "generator")
    tray.AddModule("I3Writer", "writer")(
        ("filename", "test_run_%i" % run),
        ("streams", ["Physics", "Calibration"])
    tray. AddModule("TrashCan", "the can")
    tray. Execute (nevents)
    tray.Finish()
if __main__ == "__main__":
    main()
```

- Defines processing chain
- Parameter configuration
- Implementation:
 - wrapping I3Tray class
 - using boost.python






Wrapping with boost.python

- Simple interfaces are immediately wr
- POD are mapped di Python types
- Standard container indexing suite
 - eg. vector to list, map to aret

```
#include <boost/python.hpp>
using namespace boost::python;
BOOST PYTHON MODULE(libithon)
  void (I3Trav: *Evecute 0)(void)
                                                       = &T3Trav ·· Evecute
import libithon
class I3Tray:
    def init (self):
        self.last_added = None
        self.the_tray = libithon.I3Tray()
    def AddModule(self, type, name):
        self.the_tray.AddModule(type, name)
        self.last added = name
        return self
    def AddService(self, type, name):
        self.the_tray.AddService(type, name)
        self.last added = name
        return self
    def SetParameter(self, module, param, value):
        self.the_tray.SetParameter(module, param, value)
        return self
    def __call__(self, *args):
        for pair in args:
            print self.last_added +': ', pair[0], '=', pair[1]
            self.the tray.SetParameter(self.last added, pair[0], pair[1])
        return self
    def Execute(*args):
        if len(args) == 2:
            args[0].the_tray.Execute(args[1])
        else:
            args[0].the_tray.Execute()
    def Finish(self):
        self.the_tray.Finish()
```





Analyzer's daily work

- Standard tool in HEP is ROOT (root.cern.ch)
 - IceTray module to write ROOT files (almost generic)
 - PyROOT exposes ROOT classes to Python
 - cumbersome library
- Write HDF5 files
 - IceTray module to write HDF5 files (table interface)
 - dedicated converter for every class
- Python reader for IceTray binary format
 - wrap IO classes and basic dataclasses
 - flexible, full access, easy to use
 ... a little bit slow, though





Examples

- Access to data using ROOT
 - ROOT file writer module (C++)
 - PyROOT to read ROOT file
- Access to data using HDF5 files
 - HDF5 table writer module (C++)
 - pytables to read hdf5 file
- Direct access to data from Python
 - using the wrapped IO methods



Using ROOT Files

```
void I3RootWriterModule::Configure(){
  GetParameter("RootFileName", rootfilename );
  rootfile_ = new TFile(rootfilename_.c_str(), "RECREATE");
                                                                        import svs
 tree = new TTree("aTree", "aTree");
                                                                        from icecube.icetray import I3Tray
  tree ->Branch("nModules",&nModules , "nModules/I");
                                                                        def main(source, sink):
  tree_->Branch("nStrings", &nStrings_, "nStrings/I");
 tree_->Branch("meanPulses", &meanPulses_, "meanPulses/D");
                                                                            I3Tray.load('libdataio')
                                                                            I3Tray.load('libphys-services')
                                                                            I3Tray.load('librootwriter')
void I3RootWriterModule::Physics(I3FramePtr frame){
                                                                            tray = I3Tray. I3Tray()
  // get frame object
                                                                            tray.AddModule('I3Reader', 'reader')(
  I3RecoPulseSeriesMapPtr hitsmap =
                                                                                ('filename', source))
     frame->Get<I3RecoPulseSeriesMapPtr>(pulseSeriesName);
                                                                            tray.AddModule('I3RootWriterModule', 'writer')(
 nModules_ = hitmap->size();
                                                                                ('RootFileName', 'out.root'))
                                                                            tray.AddModule('TrashCan', 'trash')
  // set to count number of strings
                                     import ROOT
  set<int> nStrings;
  // mean number of pulses per Modu
                                     def main(path):
  int nPulses = 0;
                                         f = ROOT.TFile(path)
  // loop over oms in hitmap
                                         tree = f.Get("aTree")
  typename I3Map<0MKey, vector<I3Red
                                         nentries = tree.GetEntries()
  for (hits=hitsmap->begin(); hits
   const OMKey& omkey = hits->firs
                                         nStringsLeaf = tree.FindLeaf("nStrings")
   // add hits of this om
                                         meanPulsesLeaf = tree.FindLeaf("meanPulses")
    nPulses += hits->second.size()
                                         nModulesLeaf = tree.FindLeaf("nModules")
    // track the strings hit
    nstrings.insert(omkey.GetStrind
                                         for i in xrange(nentries):
                                             tree. GetEntry(i)
                                             print 'Event %i Modules: %i <Pulses>: %.3f Strings: %i' % \
 nStrings_ = nstrings.size();
                                                   i+1, nModulesLeaf.GetValue(),
 meanPulses = nPulses/nModules ;
                                                    meanPulsesLeaf.GetValue(), nStringsLeaf.GetValue())
  tree ->Fill();
                                     if __name__ == '__main__':
                                         main(sys.argv[1])
```

Leipzig EuroScipy July 200



Using HDF5 Tables

```
void DummyModule::Physics(I3FramePtr frame) {
 // struct which is passed to HDF table writer method
 buffer = Buffer();
                                              import svs
                                              from icecube.icetray import I3Tray
  // get frame object
  I3RecoPulseSeriesMapPtr hitsmap =
                                              def main(source, sink):
     frame->Get<I3RecoPulseSeriesMapPtr>(pul
                                                  I3Tray.load('libdataio')
  // number of modules
                                                  I3Trav.load('libphys-services')
  buffer.nModules = hitsmap->size();
                                                  I3Tray.load('libhdf-writer')
  // set to count number of strings
  set<int> nStrings;
                                                  trav = I3Trav. I3Trav()
 // mean number of pulses per Module
  int meanP = 0;
                                                  tray. AddService('I3HDFWriterServiceFactory', 'hdfservice') (
                                                      ('filename', sink))
  // loop over oms in hitmap
 typename I3Map<0MKey, vector<I3RecoPulse>
                                                  tray.AddModule('I3Reader', 'reader')(
 for (hits=hitsmap->begin(); hits!=hitsmap-
                                                      ('filename', source))
   const OMKey& omkey = hits->first;
   // add hits of this om
                                                  tray.AddModule('I3HDFWriter<EventInfoToTable<I3RecoPulse > >', 'info')(
   meanP += hits->second.size();
                                                      ('tablename', 'info'),
   // track the strings hit
                                                      ('key', 'RecoPulses'))
   nstrings.insert(omkey.GetString()); //
                                                  tray.AddModule('TrashCan', 'trash')
                                                  tray.Execute()
  buffer.nstrings = nstrings.size();
                                                  tray.Finish()
  buffer.meanP = meanP/nModules;
 // now fill struct and store results in hd if __name__ == '__main__':
 H5TBappend_records
                     import sys
                     import tables
 PushFrame(frame, "(
                     def main(path):
                         f = tables.openFile(path)
                         for row in f.root.eventinfo:
                             print 'Event %i Modules: %i <Pulses>: %.3f Strings: %i' % \
                                   (row['id'], row['nmodules'],
                                    row['mean pulses'], row['nstrings'])
                     if __name__ == '__main__':
                         main(sys.argv[1])
```

IceCube



The Pythonic Way

```
import sys

    Single script

import numpy
import icecube.icetray as icetray
import icecube.dataclasses as dataclasses
import icecube.dataio as dataio
                                            No compilation
def main(path):
   # open file
                                           Developed interactively
   fh = dataio. I3File(path)
                                            using introspection - no
   # walk through frames
   while fh.more():
                                            need to check docs
       frame = fh.pop physics()
       # get reconstructed electronic signals
       hitmap = frame.Get('RecoPulses')
       # calculate number of contributing modules
       nModules = len(hitmap)
       # calculate mean number of pulses observed per module
       meanP = numpy.mean([len(entry.data()) for entry in hitmap])
       # number of strings
       nStrings = len(set(entry.key().GetString() for entry in hitmap))
       # get Event ID
       eventID = frame.Get('I3EventHeader').EventID
       print 'Event %i Modules: %i <Pulses>: %.3f Strings: %i' % \
             (eventID, nModules, meanP, nStrings)
  __name__ == '__main__':
   main(sys.argv[1])
```



Rapid Prototyping

- Simple line-fit
 - $\vec{v} = COV(\vec{r},t)/VAR(t)$
- Compare to more than 200 rows C++ code
- Great for developing new algorithms
- Great to check details in data

```
import numpy
import icecube....
def linefit(geometry, hitmap):
   # lists of module coordinates and hit times
   coords = []
   times = []
    for entry in hitmap:
        pos = geometry[entry.key()].position
        for pulse in entry.data():
           coords.append((pos.X, pos.Y, pos.Z))
           times.append(pulse.Time)
   # build numpy arrays
   coords = numpy.asarray(coords)
    times = numpy.asarray(times)
   # correlation between times and coordinates
    times -= times.mean()
   coords -= coords.mean(axis=0)
   speed = (coords * times[:,numpy.newaxis]).sum(axis=0) / \
            (times.var() * (len(times)-1))
    return speed
def main(path):
   fh = dataio. I3File(path)
   geometry = None
   while fh.more():
       frame = fh.pop_frame()
       if 'I3Geometry' in frame:
            geometry = frame.Get('I3Geometry').omgeo
        if 'RecoPulses' in frame:
            hitmap = frame.Get('RecoPulses')
            if geometry is not None:
                reco = linefit(geometry, hitmap)
                print numpy.linalg.norm(reco)
```





Modules written in Python

- Modules can be Python functions
 - Nice to write simple filters

```
#!/usr/bin/env python
from icecube.icetray import I3Tray

def filt(frame):
    return len(frame.Get("RecoPulses")) > 20

def main():
    tray = I3Tray.I3Tray()
    tray.AddModule("I3Reader", "reader")(
        ("filename", "data.i3.gz"))

    tray.AddModule(filt, "filter")

    tray.AddModule("I3Writer", "writer")(
        ("filename", "filtered" % run))

    tray.AddModule("TrashCan", "the can")
    tray.Execute()
    tray.Finish()
```

- Single script
 - No compilation

- Modules in Python
 - Derive from base module class
 - Add python class as module
 - C++ instantiates Python object and calls interface




Analysis Tools

- Numpy great data manipulation
 - Loop-less computations
 - Advanced indexing (boolean arrays) for cutting
- Scipy fitting, statistical tests, machine learning
- Matplotlib visualize data
 - Easy to learn
 - Nice for simple graphs, easy customization
 - Histogramming needs tweaks (next slide)
 - No GUI to manipulate plots






- Modified histogram function
 - Based on numpy digitize & bincount
 - Weights, stat. error calculation, errorbars, logscale, filled patches, lines, bars



- 2D-histograms
 - Digitize & bincount
 - Contour or scatter plot
 - Weights, Logscale





Summary

- IceCube uses a costumized software framework
- Controlling done using Python scripts
 - simple interface wrapped with boost.python
- Data extraction not straightforward
 - wrapping all data IO and base classes provides easy access and interfaces for prototyping and development
- Python allows extremely fast development cycles
- matplotlib, numpy, scipy provide a great environment to develop algorithms
- Tedious implementations using C++ only for time demanding tasks